



Instructions for Linking 2 SX Systems



SX Unit 1



SX Unit 2

Put Manager Card into SX Unit 2 and bring up Card Management Screen
Take Manager Card from SX Unit 1 and plug into Card reader on SX Unit 2
Select Link function (SX Unit 2 will now have the same customer ID as unit 1)
Take Old SX Unit 2 Manager Card and reinsert in Card reader on SX Unit 2
Select Make Manager card button
Both cards should now work in both machines
Now you can make cards in either unit which work in both