



## Setup Flow Chart

---




Set All Defaults



Show Version

Note: (\*) denotes default setting options marked by ( ) are only available upon request.

## Group 5: Scan Mode



ENTER GROUP



EXIT




1: Trigger On/Off



2: Trigger On/  
Good Read Off (\*)



3: Trigger On/  
Good Read Off/  
Delay Timeout = ?



4: Continuous/  
Trigger Off



5: Continuous/  
LED Always on



6: Continuous/  
No Trigger



7: Continuous/  
Testing



8: Continuous/  
Trigger Off/  
Delay Timeout = ?

### Delay Timeout Setting:

Scan Enter Group 5 Label -->

Scan 3 or 8 Label -->


Scan two digit labels in Table-Hex -->

Scan Confirm Label in Table-Hex -->

Scan Exit Label

**Note:** Scan mode setting is only available for CCD/LASER type scanner. Setting wand type scanner to this mode will cause the scanner to break down.

## Group 7: RS-232 Parameters



ENTER GROUP



EXIT



## Baud Rate



600



1200



2400



4800



9600(\*)



19200



38400



## Data Bit



BIT 7



BIT 8 (\*)

**Group 16-1: EAN-13/JAN-13**



ENTER GROUP



EXIT



Enable (\*)



Disable

**ADD-ON 2/5**



Enable



Disable (\*)

**Transmit Check Character**



Enable (\*)



Disable

**Truncate 1<sup>st</sup> digit**



Enable



Disable (\*)

**Truncate 2<sup>nd</sup> digit**



Enable



Disable (\*)

**EAN Checkdigit**



Enable (\*)



Disable